



MODERN SPARE

www.modernspare.com

Trunk Installation Instructions

We want our spare tire solution to be as convenient as possible. As such, we have designed our kit to fit in the available spare tire well of your Camaro. Please install using the following instructions:

1. Remove rubber mat from trunk if equipped.
2. Unscrew hold down piece so that decklid may be removed.
3. If equipped, remove inflator kit components.
4. Place jack, lug wrench, and disposable tire bag next to the battery. It is best to use included packaging material so that components will stay secure when stowed in tire well.
5. Place Modern Spare wheel & tire combo into the spare tire well on top of the battery. For a picture example of this please visit www.modernspare.com and view the 2010-2015 Camaro kits.
6. Place deck lid back on top of the spare tire well.
7. Use included hold-down hardware to fasten deck lid. Please note that the OEM hold down piece will not work as there are clearance issues with the spare tire.
8. Replace rubber mat if equipped.

Please note that there is a very small amount of deck lid lift that comes from the spare tire being in the tire well. Due to the required brake clearance requirements for the Camaro having a spare that causes a small amount of deck lid lift was unavoidable.

Should you have any questions please feel free to reach out to us at (801) 896-3395 or info@modernspare.com

Tire comes prefilled with 50 psi of pressure & has max speed rating of 81 MPH (112M Rating). When handling take caution not to puncture or damage the tire. It is recommended to periodically check your spare tire pressure so as to maintain it for safe vehicle use

Modern Spare does not assume any liability, express or implied for product use. User assumes all liability and responsibility for product use



MODERN SPARE

www.modernspare.com

For vehicles having front brake pads installed with harmonic weights, also known as “roller skates”, a double tire change may be necessary for a front flat. In this case, the spare would need to be installed on the rear and the rear tire then installed in place of the front flat.

Alternatively, the “roller skate” brake pads may be replaced with non “roller skate” style brake pads or the “roller skates” may be removed from the existing pads. Also, a spacer can be purchased directly from Modern Spare for \$40 that will allow for spare tire usage with “roller skate” style brake pads.

Tire comes prefilled with 50 psi of pressure & has max speed rating of 81 MPH (112M Rating). When handling take caution not to puncture or damage the tire. It is recommended to periodically check your spare tire pressure so as to maintain it for safe vehicle use

Modern Spare does not assume any liability, express or implied for product use. User assumes all liability and responsibility for product use